



 **RIMBA ELECTRO SEX STIMULATION (POWERBOX # 7850)**

The sex stimulator is a battery operated, pulse generator that sends electrical impulses to the electro parts/toys, placed on body parts. The pulse amplitude, pulse rate, pulse width with the natural motion of rotary controls can be adjusted independently, allowing precise control of the impulses. The mode selector switch with the simple switches makes all adjustments smooth and effortless.

The RIMBA nr. 7850, EROTIC STIMULATION powerbox contains;

- |                             |                     |                 |
|-----------------------------|---------------------|-----------------|
| - 1 x dual-Channel powerbox | - 4 x adhesive pads | - 3 x lead wire |
| - 1 x 9V battery            | - 2 x clamps        | - 1 x Manual    |



**Accessories (Electrodes)**

- # 7851 2 x Clamps uni-polar with lead wire.
- # 7852 2 x Breast/Body cups, bi-polar + 2 lead wires
- # 7853 Aluminium dildo, bi-polar, Ø25 x 155 mm.
- # 7854 Aluminium dildo, bi-polar, Ø35 x 165 mm.
- # 7855 Leather cock straps, bi-polar
- # 7856 Scrotum parachute + lead wire, bi-polar.
- # 7857 Aluminium anal plug, bi-polar, Ø35 x 140mm.
- # 7858 4 x self adhesive gel pads.
- # 7859 Egg small, bi-polar Ø25 x 60 mm.
- # 7860 Egg big, bi-polar Ø35 x 70 mm.
- # 7862 Aluminium cock ring / ball stretcher, bi-polar Ø35 mm. inside
- # 7863 Aluminium dildo, bi-polar Ø 25 x 125 mm.
- # 7864 Aluminium plug, balloon shape, bi-polar, Ø35 x 100 mm.
- # 7865 Aluminium dilator/sound, bi-polar, Ø 8 x 180 mm.
- # 7866 Leather cock tube with lace, bi-polar.

- # 7867 Silicone plug, small, bi-polar Ø 28 x 75 mm.
- # 7868 Silicone plug, big, bi-polar Ø 40 x 155 mm.
- # 7869 Silicone penis ring set, flat, uni polar, Ø 40 + 50 mm.
- # 7870 Silicone penis ring set, round, bi polar, Ø 40 + 50 mm.
- # 7871 Aluminium penis ring set (3 Pcs.) uni-polar, 36 + 42 + 46 mm.
- # 7873 1 self adhesive gel butterfly with pression buttons connection
- # 7874 Aluminium dildo, bi-polar Ø 16 x 160 mm.
- # 7876 Conductive glove set complete
- # 7877 Aluminium dildo with double bullet, bi-polar Ø35 x 100 mm.
- # 7878 Aluminium dildo with 5 bullets, bi-polar Ø25 x 160 mm.
- # 7879 Aluminium Anal plug, bi-polar Ø30 x 90 mm.
- # 7881 2 x Self adhesive gel pads with pression buttons connection.
- # 7882 Aluminium mini-plug, bi-polar Ø25 x 60 mm.
- # 7883 Leather cock strap with buckle, bi-polar
- # 7884 Leather cock harness with pressing buttons, bi-polar
- # 7885 Leather cock/scrotumstrap with elastic, bi-polar
- # 7886 Plastic dildo, bi-polar Ø25 x 145 mm.
- # 7887 Plastic mini plug, bi-polar Ø25 x 70 mm.
- # 7888 Aluminium Anal plug, bi-polar, Ø50 x 105 mm.
- # 7889 Set of 2 blue elastic bands for penis and /or scrotum with cable
- # 3000 Electro contact Gel, 250 ml per bottle.

#### **Warning and Precaution:**

- Do not use if you wear a cardiac-pacemaker.
- Do not use if you are pregnant.
- Do not use on eyelids.
- Do not use on broken skin.
- Avoid abrupt changes in stimulation control settings.
- Keep out of reach of children.
- Turn the powerbox off before applying, removing or changing electrodes.
- Stimulation of areas where bones are near the skin (knee, forehead or shin) can be painful in some patients.
- Stimulation controls, especially amplitude, should be adjusted slowly.
- Do not immerse the stimulation-powerbox in water or other liquids.

#### **Side effects:**

Skin irritation may occur beneath or around the electrode sites. If skin irritation persists, **discontinue** use.

#### **Using the RIMBA ELECTRO SEX STIMULATOR.**

##### **Amplitude controls.**

Control knobs 1 and 2 adjust the intensity of the stimulation for channels 1 and 2 respectively. The amplitude Control is marked from 1 to 8, increasing numbers indicate an increase in intensity of current. Each amplitude control also incorporates an ON/OFF switch. When either channel is turned on the green light will come on.

##### **Indicator Light**

When either channel is turned ON, the green indicator light in the middle is continuous glowing. The other green lights will follow the pulse rate. When the battery is low or the unit is continuing operating over 20 minutes, the power indicator light will change from green to red. The unit will shut itself OFF, this is an auto timer system. The powerbox can be reset by turning both amplitude controls OFF.

##### **Pulse Rate Control**

This control regulates the frequency of stimulation from 2 to 150 pulses per second.

##### **Pulse Width Control**

This control adjusts the duration of each individual stimulation pulse width, from 50 to 250 Micro-seconds (µS)

##### **Mode Selector Switch**

**M** = Modulation mode, contraction 4 seconds, relaxation 1 second, Pulse width and Rate remain adjustable

**N** = Normal mode, Pulse width is adjustable, 50-250 Us, Pulse rate is adjustable, 2 - 150 Hz  
**B** = Brief mode, Contraction 0,2 sec, Relaxation 0,2 sec.

### **Operating Procedure**

The RIMBA ELECTRO SEX STIMULATION system is easy to operate and maintain, if these instructions are followed;

1. Both Amplitude controls must be turned OFF.
2. Open battery compartment and insert 9V battery.
3. Switch the mode selector as wished to M, N or B and if necessary change pulses; Width and/or Rate.
4. Close the battery compartment.
5. Insert lead wire connectors into the pads or other accessory.
6. Insert other end of lead wire into the black powerbox.
7. Place the pads or accessory on the chosen body part .
8. Slowly increase the amplitude control, make sure that the connecting parts are clean and if necessary body hair is removed.
9. Be sure that the amplitude is OFF before removing electrodes.
10. When you are finished, turn off the amplitude control.

### **Technical information for Powerbox:**

Power source: 006P DC 9Volts Dry Battery  
Pulse Amplitude: 0 - 80 mA  
Pulse rate: 2 Hz - 150 Hz adjustable control  
Pulse width: 50 uS - 250 uS adjustable control  
Function Mode: Modulation-, Normal- and Burst mode  
Auto timer: 20 minutes

**TIP: Use a sufficient quantity of contact gel to create the optimal contact.  
Ref. 3000 = Rimba Electro contact gel, 250 ml.**

**Advise: turn controls knobs to maximum and select B (brief mode)  
Warning: This product is for adults only. Use at own risk.**



[www.rimba.eu](http://www.rimba.eu)